SPRING
ANGLE

AMPLITUDE STICKER
MOUNTED NEAR
FEEDER BOWL DISCHARGE

AUTOMATION DEVICES, INC.
814-474-5561

AMPLITUDE INDICATOR

.150
.125
.100
.075
.050
.025
0

P/N 0107

FEEDER AMPLITUDE
IS READ FROM THE
SCALE ADJACENT
TO THIS POINT

WHEN BOWL IS VIBRATING,
THE AMPLITUDE STICKER
WILL LOOK LIKE THIS

AMPLITUDE STICKER SHOWS IF CHANGE IS IMPROVEMENT

OPTIMIZING PARTS FEEDER PERFORMANCE FOR COST SAVING

FIGURE 7