

The Fork RhinoTM

Receiver Shackled Configuration

www.ForkRhino.com

Instructions

Maximum Capacity:

The load capacity of the Shackled Fork Rhino Receiver is limited to the interchangeable ball and insert rating.

- The shackle supplied with the Shackled Fork Rhino is rated for 6500 lbs.
- A Grade 70 chain and binder pins are suggested for attaching and securing the Shackled Fork Rhino to the forklift.
- Inserts for the Fork Rhino Receiver are available at an additional cost.

INDIVIDUAL FORK TRUCK TIPPING WEIGHT MAY DIFFER FROM THE LOAD CAPACITY OF THE FORK RHINO.

Installation

Maximum Fork Width : 6"

1. Position forks so they are 1 3/4" apart.
2. Slide Fork Rhino onto forks until fork tips press against the limiting pins.
3. Consult your forklift manufacturer's manual for instructions on properly attaching the chain to the fork truck.
4. Hook trailer safety chains to Fork Rhino carrying handles.



OPTIONAL PIN INSTALLATION:

The Shackled Fork Rhino Receiver can be converted to the Pinned Fork Rhino Receiver using 1/2" eye bolts to be inserted through pre-drilled holes in the forks. The Rhino Receiver may be used as a template for drilling fork holes making sure that the limiting pins are secure against the fork tips while transferring the hole center (final fork drill size is 17/32").

PRECAUTIONS

- Not intended for high speed or highway use.
- Consult your fork truck manual or manufacturer for maximum tipping weight.
- Do not lift equipment beyond point at which a positive tongue weight is maintained.



7050 WEST RIDGE ROAD
FAIRVIEW, PA, U.S.A 16415-2099

PHONE: 1-814-474-5561
FAX: 1-814-474-2131

WEBSITE: ForkRhino.com
EMAIL: sales@autodev.com



Made in the
USA